

# SERVICE MANUAL

MODEL  
L20A, L24 SERIES  
ENGINE



**NISSAN MOTOR CO., LTD.**  
TOKYO, JAPAN

## SECTION EC

---

### EMISSION CONTROL SYSTEM

GENERAL DESCRIPTION .....	EC- 2
CRANKCASE EMISSION CONTROL SYSTEM .....	EC- 2
EXHAUST EMISSION CONTROL SYSTEM .....	EC- 3
EVAPORATIVE EMISSION CONTROL SYSTEM .....	EC-12
MAINTENANCE AND TESTING .....	EC-14
ADJUSTING ENGINE IDLING SPEED AND GAS MAIXTURE .....	EC-20
TROUBLE DIAGNOSES AND CORRECTIONS .....	EC-24
PERIODIC RECOMMENDED MAINTENANCE .....	EC-26
SERVICE DATA AND SPECIFICATIONS .....	EC-27

**EC**

# EMISSION CONTROL SYSTEM




Fig. EC-1 Emission control system on model S30 series

## GENERAL DESCRIPTION

There are three types of emission control system to be controlled. These are;

1. Closed type crankcase emission control system
2. Exhaust emission control system
  - Air injection system (A.I.S.)
  - Engine modifications

### 3. Evaporative emission control system

Periodic inspection and required servicing of these systems should be carried out at the recommended intervals to assure better performance extended engine service life and elimination of air pollution improved to the maximum extent.

## CRANKCASE EMISSION CONTROL SYSTEM

### CONTENTS

DESCRIPTION .....	EC-2	PERIODIC SERVICE .....	EC-3
-------------------	------	------------------------	------

### DESCRIPTION

There are two types of crankcase emission control system. One is a sealed system, and the other is a closed system (with valve controlled by an intake manifold vacuum and sealed system).

The closed system is employed by the L24 engine installed on the S30 series vehicles, instead of the sealed system being used on SP/SR sport cars.

This system returns blow-by gas to both the intake manifold and carburetor air cleaner.

In addition to the above mentioned sealed system, a

variable orifice valve is used to feed crankcase blow-by gas to the intake manifold. During partial-throttle operation of the engine, the intake manifold sucks the blow-by gas through the valve. Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air. Ventilating air is drawn from the clean side of the carburetor air cleaner, through the tube connection, into the crankcase.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve, and the flow goes through the sealed system in the reverse direction. In vehicles with an excessively high blow-by, some of the flow will go through the tube connection to the carburetor air cleaner at all conditions.

## EMISSION CONTROL SYSTEM




Fig. EC-2 Closed type positive crankcase ventilation system

### PERIODIC SERVICE

Once a year or at every 18,000 km (12,000 miles), the crankcase Emission Control System should be serviced as follows.

1. Check hoses and hose connectors for leaks.
2. Disconnect all hoses and blow them out with compressed air.  
If a hose is not free from obstructions, replace with a new one.
3. Check the crankcase ventilation control valve for the correct function. If the valve is found defective replace it with a new assembly.

## EXHAUST EMISSION CONTROL SYSTEM

### CONTENTS

AIR INJECTION SYSTEM .....	EC- 4
Air pump .....	EC- 4
Air injection into each exhaust port .....	EC- 5
Anti-backfire valve .....	EC- 6
Check valve .....	EC- 7
Air pump relief valve .....	EC- 7
ENGINE MODIFICATIONS .....	EC- 7

REMOVAL, DISASSEMBLY AND INSPECTION .....	EC- 8
Air pump .....	EC- 8
Drive pulley .....	EC- 9
Anti-backfire valve .....	EC- 9
Check valve .....	EC- 9
Air gallery pipe and injection nozzles .....	EC-10

## AIR INJECTION SYSTEM




Fig. EC-3 Air injection system

The air injection pump receives clean air through a hose, connected to a fitting attached beneath the carburetor air cleaner.

This rotary vane type pump has been designed to draw air in and compress it to produce maximum air flow with quiet operation. A fresh air line from the air injection pump is routed to a check valve, which prevents exhaust gas from entering the air pump in the event exhaust manifold pressure is greater than air injection pressure, or in the case of an inoperative pump. The compressed fresh air is injected through an injection nozzle to the exhaust ports.

An anti-backfire valve has been used to eliminate "popping" in the exhaust system when the throttle is closed a high speed "coasting." Controls which have been incorporated to assure reliable system operation include an anti-backfire valve and a check valve.

## Air pump

The air pump is of a three vane type. It is a positive displacement vane-type which requires no lubricating service (maintenance free).

The die-cast aluminum air pump assembly attached to the front of the engine is driven by an air pump drive belt. A rotor shaft, drive hub, relief valve and inlet and outlet tubes are visible on the pump exterior. A rotor, vanes, carbon shoes, and shoe springs make up the rotating unit of the pump. The rotor located in the center of the pump is belt-driven. The vanes rotate freely around the off-center pivot pin, and follow the circular-shaped pump bore. In the three-vane type, the vanes form three chambers in the housing. Each vane completes a pumping cycle in every revolution of the rotor. Air is drawn into the inlet cavity through a tube connected to the air cleaner. Air is sealed between the vanes and moved into a smaller cavity (the compression area).

## EMISSION CONTROL SYSTEM


After compression, the vanes pass the outlet cavity. The vanes subsequently pass the stripper, a section of the housing that separates the outlet and inlet cavities. Continuing the cycle, the vanes again enter the inlet cavity to repeat its pumping cycle. The relief valve, located in the outlet cavity, consists of a preloaded spring, seat, and pressure-setting plug. Its function is to relieve the outlet air flow when the pressure exceeds a pre-set value. Metering grooves, machined into the housing wall, located in both the inlet and outlet cavities, provide a quiet transition from intake to compression to exhaust.

Carbon shoes support the vanes from slots in the rotor. The shoes are designed to permit sliding of the vanes and to seal the rotor interior from the air cavities. Leaf springs

which are behind the follower-side of the shoes compensate for shoe wear and vane operating sound. The rotor is further sealed by flexible carbon seals which are attached to each end. The plates also seal off the housing and end cover to confine the air to the pump cavities.

The rotating unit is a steel ring bolted to the rotor end. This ring prevents the rotor from spreading at high speed, and also positions and holds the rear bearing and the carbon seal.

The front and rear bearings which support the rotor are of two types. The front bearing uses ball bearings and the rear bearing uses needle bearings. The vane uses needle bearings. All bearings have been greased.



*Fig. EC-4 Sectional view of air pump (Three-vane type)*

### Air injection into each exhaust port

Fresh air from the air pump is injected into the individual exhaust ports of the cylinder head located near the exhaust valve.

Pressurized air is transmitted through hoses and air

distribution manifold.

A schematic of the exhaust port is shown in Figure EC-5.




Fig. EC-5 Air injection into exhaust port

In addition to the air injection system, certain controls have been incorporated to assure reliable system operation as follows.

If the valve does not work properly, the fuel mixture will go through the combustion chambers without being ignited, meet fresh air and, at high temperature, backfiring will result.

### Anti-backfire valve

This valve is controlled by intake manifold vacuum and is used to prevent exhaust system backfire at the initial duration of deceleration. At that time, the mixture in the intake manifold is too rich to burn and ignites when combined with injected air in the exhaust manifold.

The anti-backfire valve is used to provide a supply of air into the intake manifold thereby making the air mixture leaner to prevent backfire.

A schematic of the anti-backfire valve is shown in Figure EC-6.

The anti-backfire valve inlet is connected to the air pump discharge line and outlet to the intake manifold.

By burning this rapidly evaporated fuel within the cylinder, some contribution to emission reduction can also be expected.




Fig. EC-6 Anti-backfire valve

## EMISSION CONTROL SYSTEM

### Check valve

A check valve is located in the air pump discharge lines. The valve prevents the backflow of exhaust gas. Backflow of exhaust gas occurs in the following cases.

1. When the air pump drive belt fails.
2. When the spring of relief valve fails.




Fig. EC-7 Check valve


### Air pump relief valve

The air pump relief valve is mounted in the discharge cavity of the air pump and accomplishes the following functions without affecting effectiveness of the exhaust emission control system.

1. Minimizes exhaust gas temperature rise.
2. Minimizes horsepower losses resulting from air injection into the exhaust system.
3. Protects the pump from excessive back pressure.

### ENGINE MODIFICATIONS

This engine modifications system consists of a vacuum control valve which detects negative pressure of the intake manifold and operates the control valve, and a servo diaphragm which controls carburetor throttle valve in response to the vacuum control valve operation. This engine modification system has been designed so that HC emission is reduced when engine brake is applied.



1	Vacuum adjusting screw	3	Altitude corrector	5	Carburetor throttle plate
2	Vacuum control valve	4	Servo diaphragm	6	Opener adjusting screw

Fig. EC-8 Engine modification system

## REMOVAL, DISASSEMBLY AND INSPECTION

Primarily, do not remove the exhaust emission control system.

When the removal is unavoidable, however, thoroughly inspect before removing.

### Air pump

#### Removal

1. Disconnect the hoses from the air pump housing cover.
2. Remove the bolt securing the air pump to the belt adjusting bar (or adjusting bracket).
3. Remove the bolt securing the air pump to the mounting bracket and remove the air pump drive belt.
4. Dismount the air pump assembly from the vehicle.

#### Periodical service

No periodic maintenance is required since the bearings in the pump are lubrication free types. Every 5,000 km (3,000 miles), however, the belt tension should be inspected and adjusted.

#### Disassembly

1. Remove four pulley drive bolts and remove the pulley from the hub.
2. Secure the air drive hub in a vise, as shown in Figure EC-9 and remove four housing end cover bolts.

**Note:** Never clamp on the aluminum housing.




Fig. EC-9 Removing end cover

3. Remove the housing end cover by carefully tapping the surrounding of the large dowel pin with a plastic mallet and lifting up straight.

4. Put match marks on the rotor ring and side of rotor to ensure correct reassembly, and remove six screws (four screws for a two-vane type) that retain the rotor ring to the rotor, using a hexagonal wrench (special tool ST19810000).

**Note:** Generally, match marks have been indicated on both rotor ring and rotor by the manufacturer.




Fig. EC-10 Removing rotor ring

5. Remove the rotor ring and side carbon seal (for the three-vane type) from the rotor.
6. In the three-vane type, if it is necessary to replace the rear bearing, it may be pressed out of rotor ring on a press using a support for disassembling rotor ring and attachment for pushing out needle bearing.

#### Special tool

Support for disassembling rotor ring  
STECP ST19820000

Attachment for pushing out needle bearing  
STECP ST19830000

**Note:** Support rotor ring carefully to avoid distortion.


## EMISSION CONTROL SYSTEM



*Fig. EC-11 Removing rear rotor bearing*

7. Remove vanes from the rotor.

8. Remove three sets of carbon shoes and three shoe springs (two sets of carbon shoes and two shoe springs for the two-vane type) using a pair of tweezers or needle nose pliers.



*Fig. EC-12 Removing carbon shoe*

9. In the three-vane type air pump, if it is necessary to replace the relief valve, use bridge for pulling out relief valve (special tool ST19850000) and standard puller.



*Fig. EC-13 Removing relief valve*

10. No further disassembly should be attempted.


### *Cleaning-inspection-lubrication*

#### *Cleaning*

Clean the rear bearing and vane hub bearings solvent. Remove carbon dust from pump housing and rotor assembly with compressed air.

**Note:** Do not use cleaning solvent on pump housing and rotor assembly.

MEMO:



*Fig. EC-14 Components of three-vane type air pump*

## Inspection

Inspect all parts for chipping, scoring, wear and roughness.

All damaged parts must be replaced to ensure quiet and efficient operation.

If especially side carbon seal is scored, replace with a new one (for the three-vane type).

Carbon dust may be present in the housing and is usually an indication of normal wear.

## Lubrication


The rear bearing and vane hub bearings must be lubricated with a high melting point grease such as ESSO ANDOK 260 or equivalent. Grease each bearing to insure adequate lubrication.

**Note:** Bearings for service are already packed with high melting point grease.

## Assembly of air pump

1. Place the air pump housing in a vise, clamping the pump drive hub between jaws.

2. Assemble vanes correctly on dummy shaft 9.5 mm (0.3740 in) diameter. (special tool ST19860000)



*Fig. EC-15 Vane assembly*

3. Place vanes into rotor. In the three-vane type make sure that one vane is against housing stripper, and do not remove the dummy shaft at this time.

## EMISSION CONTROL SYSTEM

**Note:** a. Pack the vane hub bearing with high melting point grease such as ESSO ANDOK 260.

b. The vanes may require five to ten miles wear-in running time. In the event a slight squeaking still persists the vehicle should be run through two or three full throttle shift points. In most cases five to ten miles will be sufficient for wear-in.

4. Insert one carbon shoe on each side of every vane.

**Note:** Each carbon shoe must be positioned so that chamfered end of shoe faces to vane.

5. Insert the shoe spring into each deeper shoe slot.

**Note:** When springs are properly positioned, they will be flush or below rotor surface. The curved portion of spring will be against the shoe and ends will be against wall of shoe slot.

6. In the three-vane type, if rear bearing was removed, a new bearing may be pressed into rotor ring using attachment for pressing in needle bearing (special tool ST19840000). The bearing should be about 0.8 mm (0.0315 in) below rotor ring surface.

**Note:** Press only on lettered end bearing surface and support rotor ring to prevent its distortion.

7. Position new carbon seal on rotor ring so that holes line up.

8. Position the rotor ring so that scribe marks on rotor ring and side of rotor line up.

9. Apply thread locking material to rotor ring retaining screws and tighten them to 30 to 50 kg-cm (2.2 to 3.6 ft-lb).

10. Remove the dummy shaft from vanes and start housing end cover assembly into position (for the three-vane type), indexing vane shaft into vane bearings. Do not force cover on since it will distort vane bearings and/or vane bearing alignment.

11. Install the end cover on the housing and starting with bolt adjacent to large dowel, tighten four end cover bolts to 100 to 130 kg-cm (7.2 to 9.4 ft-lb). Remove the air pump from the vise.

12. Insert the relief valve into housing mounting hole. With protective plate over valve, tap gently with plastic mallet until the valve shoulders on the housing.

**Note:** Care must be observed to prevent distortion of air pump housing.

13. Install the silencer on relief valve by hand (for the three-vane type).

### Reinstalling the air pump

Reinstall the air pump in reverse sequence of removal, noting the following points.

Adjust the belt tension so that it has about 12.7 mm (0.5 in) of slack under thumb pressure.

### Drive pulley

1. Loosen the air supply pump adjusting bar nut and bolt to relieve the belt tension.

2. Remove the drive pulley attaching bolts.

### Anti-backfire valve

When removing the anti-backfire valve, disconnect the hoses. No further disassembly should be done. After installation, check the valve operation and inspect all hoses and hose connections for leaks.

### Check valve

1. Disconnect the air supply hose.

2. Remove the check valve from the air gallery pipe holding the flange of air gallery pipe with a wrench.

**Note:** a. Be careful not to damage the air gallery pipe.

b. No further disassembly should be done.

3. Reinstall the check valve in reverse sequence of removal.

**Note:** Tightening torque 9.0 to 10.5 kg-m (65 to 76 ft-lb)

4. After installation, check the valve, hoses and hose connections for air leakage.

## ENGINE

### Air gallery pipe and injection nozzles

It is very difficult to remove the air gallery from the exhaust manifold without bending the pipe, which could result in fractures or leakage. Therefore, the removal of the air gallery pipe and injection nozzles should be done only when they are damaged.

1. Lubricate around the connecting portion of the air injection nozzle and air gallery with engine oil.
2. Hold the air injection nozzle hexagon head with a wrench and unfasten the flare screw connecting the air gallery to injection nozzle. Remove the air gallery.

**Note:** a. Apply engine oil to the screws several times during the above work.  
b. Be careful not to damage other parts.

3. Unfasten the air injection nozzle from the cylinder head applying the engine oil to the screwed portion several times.
4. Check the air gallery and nozzle for fractures or leakage. Clean the air injection nozzle with a wire brush.
5. At the time of installation, assemble the nozzle seat on the injection nozzle and tighten the air injection nozzle to a torque of 5.7 to 7.6 kg-m (41 to 55.0 ft-lb).
6. Hold the air injection nozzle hexagon head with a wrench and tighten the flange screw of the air gallery to a torque of 5.0 to 6.0 kg-m (36 to 43 ft-lb).
7. Check the cylinder head, air injection nozzle and air gallery for leaks with the engine running.

## EVAPORATIVE EMISSION CONTROL SYSTEM

### CONTENTS

DESCRIPTION .....	EC-12	FLOW GUIDE VALVE .....	EC-13
-------------------	-------	------------------------	-------

### DESCRIPTION

This system is composed of the following four basic elements.

1. Fuel tank with positive sealing filler cap
2. Vapor-liquid separator
3. Vapor vent line
4. Flow guide valve

When the engine is at rest, the vapor vent line, vapor liquid separator and fuel tank are filled with evaporation gas produced in the closed type fuel tank. A flow guide valve opens when the gas pressure exceeds 10 mmHg (0.4 in Hg). The gas passed through the flow guide valve (2) is straged into the crankcase. Once the engine starts operation, evaporation gas in crankcase, manifold and carburetor air cleaner are sucked into the manifold for combustion. When the pressure of the closed type fuel tank, vapor liquid separator and vapor vent line becomes negative by decreasing the fuel, the flow guide valve (1) opens to send fresh air from the carburetor air cleaner to the fuel tank.

# EMISSION CONTROL SYSTEM




Fig. EC-16 Evaporative emission control system

## FLOW GUIDE VALVE

This valve operates to prevent reverse flow of blow-by gas from the crankcase. This valve is mounted inside the engine compartment. A, F and C marks are engraved in the body of the valve to indicate the connection of the vapor vent line.




Fig. EC-17 Flow guide valve

# MAINTENANCE AND TESTING

## CONTENTS

GENERAL MAINTENANCE .....	EC-14	Testing of anti-backfire valve .....	EC-16
Carburetor .....	EC-14	Testing of air pump .....	EC-16
Distributor .....	EC-14	ENGINE MODIFICATIONS .....	EC-17
Spark plug .....	EC-14	Routine inspection .....	EC-17
High tension cable .....	EC-15	Inspection at every 20,000 km (12,000 miles) .....	EC-17
Battery .....	EC-15	EVAPORATIVE EMISSION CONTROL	
Air cleaner element .....	EC-15	SYSTEM .....	EC-19
CRANKCASE EMISSION CONTROL		Checking of fuel tank, vapor-liquid	
SYSTEM .....	EC-15	separator and vapor vent line .....	EC-19
AIR INJECTION SYSTEM .....	EC-15	Checking of flow guide valve .....	EC-20
Testing of check valve .....	EC-16		

## GENERAL MAINTENANCE

To make sure that exhaust emissions are maintained at a low level, it is recommended that inspection be conducted every 12 months or every 20,000 km (12,000 miles), whichever occurs first. Best engine operation and minimum exhaust emissions will be obtained through periodical inspections and from recommended servicing at these intervals.

### Carburetor


Check the choke setting and adjust to the specifications as required.

Proper carburetor idle mixture adjustment is imperative for best exhaust emission control.

Refer to the article given in "Setting ignition timing and adjusting idle speed and mixture".

### Distributor

Check the distributor breaker points for abnormal pitting and wear. Replace if necessary. Make sure they are in correct alignment for full contact and that point dwell and gap are correct. Clean and apply distributor grease to the cam and wick. Breaker points should be replaced at intervals not to exceed 20,000 km (12,000 miles).



*Fig. EC-18 Checking of distributor breaker point gap*

### Spark plug

Remove and clean plugs in a sand blast cleaner. Inspect each spark plug. Make sure that they are of the specified heat range. Inspect insulator for cracks and chips. Check both center and ground electrodes. If they are excessively worn, replace with new spark plugs. File center electrode flat. Set the gap to 0.80 to 0.90 mm (0.0315 to 0.0355 in) by the use of a proper adjusting tool. Spark plug should be replaced every 20,000 km (12,000 miles).

## EMISSION CONTROL SYSTEM




Fig. EC-19 Checking of spark plug point gap

### High tension cable

Use an ohmmeter to check resistance on secondary cables. Disconnect cable from spark plug and install the proper adaptor between cable and spark plug. Remove the distributor cap from the distributor with secondary cables attached. Do not remove the cables from the cap.

Connect the ohmmeter between the spark plug adaptor and the corresponding electrode inside the cap. If the resistance is more than 15,000 ohms, remove the cable from cap and check cable resistance only. If the resistance is still more than 15,000 ohms, replace cable assembly.




Fig. EC-20 Checking of high tension cables

### Battery

Measure specific gravity of electrolyte with an accurate hydrometer. Specific gravity should be 1.220 or more at the standard. Add mineral free water (distilled water) as required to bring electrolyte up to proper level.

Clean battery posts and cable terminals. After tightening clamps, coat the battery posts and clamps slightly with grease to retard corrosion.

### Air cleaner element

#### Carburetor air cleaner element

The paper element has been specially treated, and therefore, there is no need to clean it. But it should be replaced every 40,000 km (24,000 miles).

## CRANKCASE EMISSION CONTROL SYSTEM

1. Check hoses and hose connections for leaks.
2. Disconnect all hoses and blow them out with compressed air.  
If any hose can not be freed of obstructions, replace with a new one.
3. Testing of the crankcase ventilation control valve.

With engine running at idle, remove the ventilator hose from the crankcase ventilation control valve. If the valve is working, a hissing noise will be heard as air passes through the valve and a strong vacuum should be felt immediately when a finger is placed over the valve inlet. If valve is plugged, do not attempt to clean it. Replace with a new valve. Check for deposit plugging in the hose. Clean if necessary.

## AIR INJECTION SYSTEM

The following procedures are recommended for checking and/or verifying that the various components of the exhaust emission control system are operating properly.

The engine and all components must be at normal operating temperatures when the tests are performed. Prior to performing any extensive diagnosis of the exhaust control system, it must be determined that the engine as a unit is functioning properly. (Disconnect the anti-backfire valve vacuum sensing hose and air supply hose at the intake manifold connections. Plug the manifold connector to preclude leakage. Plug the anti-backfire valve vacuum

sensing hose to close the passage the intake manifold ... A.I.S.). After checking the normal engine operation, reinstall all the A.I.S. parts.

### Testing of check valve

This test can be performed at the same time as the air pump test.

1. Operate the engine until it reaches normal operating temperature.
2. Inspect all hoses and hose connectors for obvious leaks and correct as necessary before checking the valve operation.
3. Visually inspect the position of the valve plate inside the valve body. It should be lightly positioned against the valve seat away from the air distributor manifold.
4. Insert a probe into the valve connection on the check valve and depress the valve plate. It should freely return to the original position, against the valve seat, when released.
5. Leave the hose disconnected and start the engine. Slowly increase the engine speed to 1,500 rpm and watch for exhaust gas leakage at the check valve. There should not be any exhaust leakage. The valve may flutter or vibrate at idle speeds, but this is normal due to exhaust pulsations in the manifold.
6. If the check valve does not meet the recommended conditions, replace it.

### Testing of anti-backfire valve

1. Operate the engine until it reaches normal operating temperature.
2. Inspect all hoses and hose connections for obvious leaks, and correct, if necessary, before checking the anti-backfire valve operation.
3. Disconnect the air hose to intake manifold at the anti-backfire valve. Insert a suitable plug in the hose and fasten it securely.
4. Open and close the throttle valve rapidly, if air flow

is felt for one to two seconds by a finger at anti-backfire valve outlet to the intake manifold, the valve functioning properly.

If air flow is not felt or air flow is felt continuously more than two seconds, the valve should be replaced.

5. Connect the air hose to intake manifold and disconnect the air inlet hose from the air pump at the anti-backfire valve. If engine idle speed changes excessively, the valve function is not correct and it should be replaced.

**Note:** In case of idle racing anti-backfire valve cannot be considered abnormal even if these exists after-burning, since it never comes out while running.

### Testing of air pump

1. Operate the engine until it reaches normal operating temperature.
2. Inspect all hose, hose connections, air gallery for leaks and correct, if necessary, before checking the air injection pump.
3. Check the air injection pump belt tension and adjust to specifications if necessary.
4. Disconnect the air supply hose at the check valve.
5. Insert the open pipe end of the air pump test gauge adapter (special tool ST19870000) in the air supply hose. Clamp the hose securely to the adapter to prevent it from blowing out. Position the adapter and test gauge so that the air blast emitted through the drilled pipe plug will be harmlessly dissipated.
6. Install a tachometer on the engine. With engine speed at 1,500 rpm observe the pressure produced at the test gauge.  
Air pressure should be 16 mmHg (0.63 in Hg) or more.
7. If the air pressure does not meet the above pressures, proceed as follows:
  - (1) Repeat 2 and 3 above.
  - (2) Disconnect and plug of the air supply hose to the

## EMISSION CONTROL SYSTEM

anti-backfire valve, clamp the plug in place, and repeat the pressure test.

(3) Check the filter element.

(4) With engine speed at 1,500 rpm close the hole of the test gauge by finger. If a leaking sound is heard or leaking air is felt by finger at the relief valve, the relief valve is malfunctioning. The relief valve should be replaced or repaired.

(5) If the air injection pump does not meet the minimum requirement of the pressure test, it should be replaced.



*Fig. EC-21 Testing of relief valve*

### ENGINE MODIFICATIONS

The control valve used in the Model L24 engine self-contains an altitude compensating device so that the control valve operates correctly also at a high land (where the air is rare) and characteristics of this control valve allow the control valve changing its operating negative pressure in approximately proportion to the atmospheric pressure. (Refer to Figure EC-8.)

#### Routine inspection

The control valve operating negative pressure is precisely adjusted when shipped from the plant, and therefore, no complicated adjustment is required normally.

Normally, it will be sufficient to conduct the following inspections.

After completing the adjustment of idling speed, with the engine which is performing air injection;

1. Increase the engine speed once up to 2,000 rpm without applying load, and release the accelerator linkage from holding with hand quickly.
2. The servo diaphragm operates once at the full stroke 5 mm (0.1969 in), the stroke returns gradually as the speed lowers, and when the speed returns to the idling speed, the operation will be released completely.
3. It is normal that time required in lowering speed from 2,000 rpm to 1,000 rpm ("T" in Figure EC-23) is approximately three seconds.

In the event of the following cases, adjustment or replacement of parts concerned is required.

First, perform adjustment in accordance with the instructions for periodical inspection and adjustment.

4. In the case that the servo diaphragm operates continuously and speed does not lower, or time required in lowering speed from 2,000 rpm to 1,000 rpm is too long (six seconds or longer) and speed does not return to the idling speed timely.

Cause: Control valve operating negative pressure is too low (low boost).

5. In the case that the servo diaphragm does not operate, or the servo diaphragm operates but does not fully stroke.

Cause: Control valve operating negative pressure is too high (high boost).

#### Inspection at every 2,000km (12,000 miles)

Control valve operating negative pressure changes in response to altitude as described previously. Hence, operating negative pressure to be adjusted should change in response to the altitude (the atmospheric pressure) of the place where the vehicle is driven. Figure EC-22 indicates relationship between operating pressure to be adjusted and altitude (atmospheric pressure).




Fig. EC-22 Operating negative pressure of control valve

How to read the Figure EC-22:

- o When the atmospheric pressure of the place where the vehicle is driven is known, read the operating negative pressure by following "A" arrow mark.
- o When the atmospheric pressure is unknown, read operating negative pressure by following "B" arrow mark from the altitude of that place.

When operating negative pressure to be adjusted is known, conduct inspection and adjustment in accordance with the following instructions. Referring Figure EC-26.

(With the engine for which idling speed adjustment has been completed and which is performing air injection)

1. Connect a vacuum gauge to the connector-AB valve (7).
2. Raise the speed once up to 2,000 rpm without applying load, and release the accelerator linkage from holding by hand quickly.
3. Make sure that the manifold vacuum rises, control valve operates, the manifold vacuum is transferred to the servo diaphragm, and that the servo diaphragm operates

once at the full stroke 5 mm (0.1969 in).

4. Thereafter, both speed and manifold vacuum reduce, or when one to two seconds are elapsed, both of them stop lowering. Figure EC-23 shows these phenomena.




Fig. EC-23

## EMISSION CONTROL SYSTEM

5. Manifold vacuum at that time is called "Operating negative pressure".

Loosen the lock screw (2) and adjust the vacuum adjusting screw (1) correctly so that the operating negative pressure meets the value obtained from the Figure EC-22.

When the above described phenomena cannot be identified, drive the vehicle actually and perform coasting. The phenomena will be verified more practically.

When actually driven and such phenomena still cannot be identified, the operating negative pressure of the control valve is unusually deviated or the control valve is damaged, or servo diaphragm is erroneously adjusted or damaged.

6. Upon completion of the above described adjustments, confirm the operation through conducting the routine inspection, and make sure that time required in lowering speed from 2,000 rpm to 1,000 rpm without applying load is less than 6 seconds.

2. Disconnect the vapor vent line connecting flow guide valve to vapor-liquid separator.

3. Connect a 3-way connector, a manometer and a cock (or an equivalent 3-way change cock) to the end of the vent line.

4. Supply fresh air into the vapor vent line through the cock little by little until the pressure becomes 14.5 in Aq.

5. Shut the cock completely and leave it that way.

6. After 2.5 minutes, measure the height of the liquid in the manometer.

7. Variation of height should remain within 1.0 in Aq.

8. When the filler cap does not close completely the height should drop to zero in a short time.

9. When the filler cap is removed, and the height does not drop to zero in a short time, it is the cause of the stuffy hose.

## EVAPORATIVE EMISSION CONTROL SYSTEM

### Checking of fuel tank, vapor-liquid separator and vapor vent line

1. Check all hoses and fuel tank filler cap.

Note: When the vent line is stuffy, the breathing in fuel tank is not thoroughly made, thus causing insufficient delivery of fuel to engine or vapor lock. It must therefore be repaired or replaced.




Fig. EC-24 Checking of evaporative emission control system

## Checking of flow guide valve

1. Disconnect all hoses from the flow guide valve.
2. While lower pressure air is pressed into the flow guide valve from the ends of vent line of fuel tank side, air should go through the valve and flow to crankcase side. If air does not flow, the valve should be replaced. But when air is blown from crankcase side, it should never flow to other two vent lines.
3. While air is pressed into the flow guide valve from carburetor air cleaner side, it flows to the fuel tank side and/or crankcase side.
4. This valve opens when the inner pressure is 10.16 mm Hg (0.4 in Hg). When operation is improper or breakage exists, replace it.





Fig. EC-25 Flow guide valve

## ADJUSTING ENGINE IDLING SPEED AND GAS MIXTURE



1	Vacuum adjusting screw	6	Servo diaphragm	11	Throttle shaft
2	Lock screw	7	Connector-A.B. valve	12	Air cleaner air horn
3	Control valve	8	Auxiliary throttle shaft	13	Opener adjusting screw
4	Connector control valve	9	Vac. tube-control valve	14	Balance screw
5	Vac. tube-servo diaphragm	10	Throttle adjusting screw		

Fig. EC-26 Carburetor linkage

## EMISSION CONTROL SYSTEM

1. Remove the air cleaner cover and oil damper cap, raise the suction piston by finger, and make sure that the suction piston can be raised smoothly.
2. Check oil level, and add oil (MS#20 or 10W-30) if insufficient.




Fig. EC-27 Checking damper oil level

3. Start the engine and warm up until the water temperature rises sufficiently.

Note: a. It is desirable to warm up engine by driving the vehicle (by applying load to the engine). However, when warming up engine with the vehicle stopped (without attending), pull the throttle control knob proper to increase the engine idling speed. It is undesirable to increase the engine speed with other adjust screws. (Erroneous adjustment may occur.) However, when adjusting the engine at a repair shop or plant after dismounting it from the vehicle, recommend the engine speed be increased by screwing the opener adjusting screw ⑬. (The servo diaphragm may be connected directly to the intake manifold if required. In other word, the operation described in paragraph 8. below may be done.) In the subsequent process, however, return the opener adjusting screw to the correct position without fail. (The operation described in paragraph 9.).

b. When the engine idling speed is adjusted with fast idle setting screw, the engine speed is often unstabilized during idling. In spite of this fact,

engine idling speed is adjusted with fast idle setting screw in many cases at the market. In order to avoid such an undesirable adjustment, this screw should not be used.




Fig. EC-28 Fast idle setting screw

4. Connect an engine tachometer and timing light.
5. Apply a flow meter to the air horn ⑫ of the air cleaner, and properly adjust the throttle adjusting screws ⑩ and ⑪ on the front and rear carburetors so that the front and rear carburetor intake air volumes are balanced and the idling speed is adjusted to 750 rpm.




Fig. EC-29 Setting flow meter

## ENGINE

Note: a. Recommend the engine be raced whenever the throttle adjusting screws are turned for successful adjustment.

b. The flow meter is used to hinder the engine from intaking air, and therefore, recommend the flow meter be used for short period of time (one to two seconds) intermittently (should not be used continuously).

When the flow meter is applied to the air horn ⑫, the engine speed lowers and adjustment may not

be made correctly.

c. When the throttle adjusting screw is returned during the above adjustment and engine speed cannot be reduced below 750 rpm, other adjusting screws such as opener adjusting screw ⑬ and balance screw ⑭ must have been tightened excessively or the accelerator linkage must have not been adjusted correctly. Under the normal condition, the auxiliary throttle shaft ⑧ and throttle shaft ⑪ should have a slight play during engine operation under the idling speed. In other words, the auxiliary throttle shaft ⑧ should be provided with a play "Q1" which corresponds to the clearance  $T_a = T_b$  as shown in Figure EC-30.




Fig. EC-30 Adjusting idle speed and mixture

## EMISSION CONTROL SYSTEM

6. Adjust the ignition timing to  $5^{\circ}$  BTDC (Before Top Dead Center).




Fig. EC-31 Adjusting ignition timing

7. When the ignition timing is adjusted and engine speed is changed, repeat the adjustments described in paragraph 5 above.

8. Disconnect the control valve vacuum tube ⑨ from the control valve connector ④, and connect the servo diaphragm vacuum tube ⑤ to the control valve connector ④ [Apply manifold booster to the servo diaphragm ⑥.]

9. Adjust the opener adjusting screw ⑬ so that the engine speed is 1,200 rpm under the condition described in paragraph 8. above.

10. Maintaining the condition described in paragraph 8 and 9 above as is, use a flow meter and adjust the balance screw ⑭ properly so that the front and rear carburetor intake air volumes are balanced.

11. Repeat the adjustment described in paragraph 9 above (At the same time, disconnect the servo diaphragm vacuum tube ⑨ once from the connector ④, reconnect the servo diaphragm vacuum tube ⑨ to the connector

④, and make sure that the engine speed is 1,200 rpm. Readjust, if the engine speed is not 1,200 rpm.), and reconnect the control valve vacuum tube ⑨ to the control valve connector ④ and servo diaphragm vacuum tube to the original position.

12. When a CO meter is available, tighten the idling speed adjusting nuts located beneath the front and rear carburetors equally from positions where the nuts come into contact with the stoppers (idling lock nuts), and thus, adjust CO level to  $6 \pm 1\%$ .

(This adjustment should be made without feeding air from the air pump.)

When CO meter is not available, primarily, mixture ratio adjustment is not recommended.

When engine idling operation is noticeably unstable, however, adjust as follows.

13. Tighten both front and rear carburetor idling adjusting nuts in a half of one full turn 0.5 mm (0.019 in) from positions where the nuts come into contact with the stoppers (idling lock nuts).

If the engine still operates unstably, adjust as follows.




Fig. EC-32 Idle adjust nut

14. Tighten both the front and rear carburetor idling adjusting nuts equally from positions where the nuts come into contact with the stoppers (idling lock nuts), and thus, adjust the engine speed to the best slow-speed.

## ENGINE

# TROUBLE DIAGNOSES AND CORRECTIONS

## CONTENTS

EXHAUST EMISSION CONTROL  
SYSTEM ..... EC-24

Air pump ..... EC-25

## EXHAUST EMISSION CONTROL SYSTEM

A preliminary "Diagnosis Guide" is included below as an aid in trouble shooting the exhaust emission control system.

Troubles	Possible causes
Excessive backfire in exhaust system	<ul style="list-style-type: none"><li>• Anti-backfire valve vacuum line collapsed, plugged, disconnected or leaking</li><li>• Defect or malfunction of the anti-backfire valve resulting in insufficient air delivery to the intake manifold or insufficient duration time to the engine requirement</li><li>• Incorrect idle mixture adjustment</li><li>• Defect or malfunction of the spark plug or high tension cables</li></ul>
Air supply hose baked	<ul style="list-style-type: none"><li>• Defective check valve on air distribution manifold</li></ul>
Rough engine idle	<ul style="list-style-type: none"><li>• Incorrect carburetor adjustment of idle speed, idle mixture, choke setting</li><li>• Incorrect basic ignition timing</li><li>• Leak of vacuum at the anti-backfire valve vacuum line or air inlet hose</li><li>• Defective or stucked anti-backfire valve</li></ul>
Engine surges at all speed.	<ul style="list-style-type: none"><li>• Defective or stucked anti-backfire valve</li><li>• Incorrect carburetor adjustment of idle speed, idle mixture, choke setting</li></ul>
Engine stop	<ul style="list-style-type: none"><li>• Incorrect carburetor adjustment of idle speed, idle mixture, choke setting</li><li>• Incorrect basic timing</li><li>• Disconnection of vacuum tube of the anti-backfire valve</li></ul>
Noisy air pump drive belt	<ul style="list-style-type: none"><li>• Drive belt improperly adjusted</li><li>• Seized or failing air pump</li><li>• Misaligned or defective pulley</li></ul>

# EMISSION CONTROL SYSTEM

## Air pump

### When mounted on the vehicle

#### Noise-external cause

The air injection pump is not completely noiseless. Under normal conditions, noise rises in pitch as engine speed increases.

If excessive noise is heard;

1. Make sure that the pump rotates correctly, and check the belt for proper tension.
2. Check hoses for tightness, leaking or touching with other parts.
3. Check the pump mounting bracket and the air cleaner for secure installation.
4. Check relief valve for escaping air.

#### Noise-internal cause

##### 1. Vane noise

A "chirping" or "squeaking" noise is most commonly associated with vanes rubbing in housing bore. Vane chirping is most noticeable at low speed and is heard intermittently. Additional wear-in time may eliminate this condition. If additional wear-in time does not eliminate chirp, the pump must be disassembled, and the vanes and carbon shoes should be replaced.

##### 2. Bearing noise

A rolling sound indicates bearing noise. This sound will be noticeable at all speeds, but does not necessarily indicate bearing failure. However, if noise increases to an objectionable level, the bearing

may have to be replaced.

##### 3. Rear bearing noise

This noise is identified by a continuous knocking sound. When this noise occurs dismount the pump from the vehicle and inspect carefully.

### Off car

1. With the pump removed from the vehicle, rotate drive hub in jerks three-quarters of one full turn forward and one-quarter of one full turn backward. If roughness or bumps are felt, remove the rear cover.

2. Inspect carbon seal. This seal should not have any holes caused by wear or be broken or cracked. Such condition commonly results from defective rear and/or vane bearing. A failed seal must be replaced.

3. With rear rotor ring and carbon seal removed, pull out the vanes. Vane bearing failure is also indicated by absence of grease or caked grease. Inspect vane shaft to confirm this bearing failure. All corners of vanes should be square. When edges are broken, replace the vanes.

4. Remove carbon shoes and inspect surface contacting with the vane. Small grooves in shoes are normal. Replace, if chipped or broken. Broken shoes indicate improper assembly of shoe springs. Damaged shoes must be replaced and springs must be properly installed.

5. Carbon dust may be present on vanes and in housing. This is an indication of normal wear. Remove carbon dust by blowing compressed air to the parts in question.

Troubles	Possible causes	Corrective action
Inoperative pump	Trouble in pump	Replace with new pump.
	Excessive slackness of drive belt	Adjust drive belt tension to specified value.
Insufficient delivering air	Damaged vane hub bearing	Replace.
	Worn vane	Replace.
	Worn carbon shoe	Replace.
	Worn side seal	Replace.

## ENGINE

Air leakage	Leakage from hoses, connectors or clamps	Ammend or tighten. Replace if necessary.
	Leakage from relief valve	Replace relief valve.
Abnormal noise	Stick of air pump	Replace with new assembly.
	Slackness of drive belt (in accelerating)	Adjust drive belt tension.
	Leakage from hoses, connectors or clamps	Retighten or replace.

## PERIODIC RECOMMENDED MAINTENANCE

Periodical inspection and required servicing of these system should be carried out at the recommended intervals to assure better engine performance, extended engine service life and completely eliminated air pollution.

Item	Interval
<b>1. Engine</b>	
Check ignition timing.	every 5,000 km ( 3,000 miles)
Check engine idling.	5,000 km ( 3,000 miles)
Engine tune-up	20,000 km (12,000 miles)
Check spark plugs.	5,000 km ( 3,000 miles)
Replace spark plugs.	20,000 km (12,000 miles)
Check high tension cables.	20,000 km (12,000 miles)
Check for pitting and wear of distributor breaker points.	5,000 km ( 3,000 miles)
Replace distributor breaker points.	20,000 km (12,000 miles)
Apply grease to distributor rotor shaft.	20,000 km (12,000 miles)
Apply grease to distributor cam and wick.	20,000 km (12,000 miles)
Replace carburetor air cleaner element.	40,000 km (24,000 miles)
<b>2. Crankcase emission control</b>	
Check hoses and hose connections for leaks.	every 20,000 km (12,000 miles)
Check for correct function of crankcase ventilation control valve.	20,000 km (12,000 miles)

## EMISSION CONTROL SYSTEM

<p>3. Exhaust emission control</p> <p>Check for correct function of air pump.</p> <p>Check for correct function of relief valve.</p> <p>Check for correct function of check valve.</p> <p>Check for correct function of anti-backfire valve.</p> <p>Check air gallery and nozzle connections for leaks.</p> <p>Check hoses and hose connections for leaks.</p> <p>Check air pump belt tension.</p> <p>Check operating negative pressure of throttle control valve, adjust if necessary.</p>	<p>every 20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p> <p>5,000 km (3,000 miles)</p> <p>20,000 km (12,000 miles)</p>
<p>4. Evaporative emission control</p> <p>Check hoses, hose connectors and piping for leaks.</p> <p>Check for correct function of flow guide valve.</p>	<p>every 20,000 km (12,000 miles)</p> <p>20,000 km (12,000 miles)</p>

## SERVICE DATA AND SPECIFICATIONS

### Specifications

<p>Air pump</p> <p>Type ..... ECP200-3</p> <p>Capacity ..... 200 cc (12.2 cu in)/rev.</p> <p>Pulley ratio ..... 0.95</p>	
<p>Anti-backfire valve</p> <p>Type ..... AV54-1B</p> <p>Duration time ..... 1.5 to 1.9 sec./500 mm Hg (19.7 in Hg)</p> <p>Orifice diameter ..... 6.0 mm (0.236 in)</p>	
<p>Check valve</p> <p>Type ..... CV27-2</p> <p>Opening pressure ..... 3.8 mmAq (8.15 in Aq)</p>	

## ENGINE

### Flow guide valve

Type ..... FGA-3  
Opening pressure ..... 10 mmHg (0.4 in Hg)

### Control valve

Type ..... TPA28-2  
Operating negative pressure ..... 510 to 540 mmHg (20.1 to 21.3 in Hg)/50°C (122°F)  
Bellows outer diameter ..... 26 mm (1.024 in)

### Servo diaphragm

Type ..... SD46-1  
Stroke ..... 5 mm (0.197 in)

### CO percent setting (with air pump disconnected)

Manual transmission .....  $6 \pm 1\%$

### Idling speed

Manual transmission ..... 750 rpm

### Ignition timing

Manual transmission ..... 5° BTDC/750 rpm

## Service data

### Tightening torque

Air pump bracket to cylinder block bolt ..... 1.0 to 1.3 kg-m (7.2 to 9.4 ft-lb)  
Air pump to adjust bar bolt ..... 2.2 to 2.5 kg-m (15.9 to 18.1 ft-lb)  
Air pump to bracket bolt ..... 2.2 to 2.5 kg-m (15.9 to 18.1 ft-lb)  
Adjusting bar to front cover bolt ..... 1.0 to 1.3 kg-m (7.2 to 9.4 ft-lb)  
Air gallery to exhaust manifold plug ..... 5.0 to 6.0 kg-m (36.2 to 43.4 ft-lb)  
Check valve to air gallery ..... 9.0 to 10.5 kg-m (65.1 to 75.9 ft-lb)

## EMISSION CONTROL SYSTEM

**SERVICE JOURNAL OR BULLETIN REFERENCE**[illegible]

[illegible][illegible]